# HuddleCamHD 20X G2 Conferencing Camera

**DATA SHEET** 

# Compatibility

- Windows 7/8/8.1/10
- Mac OS X
- Acano
- Adobe Connect
- BlueJeans
- · Cisco Jabber
- Cisco WebEx
- Easymeeting
- Facetime
- Fuzebox
- Google Hangout
- GoToMeeting
- Lifesize
- Skype for Business(Lync)
- Polycom RealPresence
- Radavision
- Spontania
- Skype
- TurboMeeting.US
- Vidyo
- Vsee
- Zoom.US
- · Google Hangouts on Air

MANUFACTURER

WARRANTY

Warranty **\*** 

YouTube Live

# **Features**

- · 20X Optical Zoom
- USB 3.0 \*(requires quad core processor)
- USB 2.0 \*(640x480 only)
- RS-232
- 1920 x 1080
- 58° Field of View
- Up to 60fps
- 64 Presets





2. **IR Receiver**To receive IR remote controller signal

3. **Power LED**Blue LED blinks when unit is powered

4. **Standby LED**Orange LED blinks
for Stand-By status

# **HuddleCamHD**

Model Number: HC20X-GY-G2





# 5. **IR Receiver**To receive IR remote controller signal

The HuddleCamHD 20X Gen 2 is

ideal for medium to large sized

meeting rooms. Comes standard

with a certified SONY lens

# 6. **USB 3.0 Interface**For connection to PC USB 3.0 port

(also compatible with USB 2.0 port and driver)

7. IR Selective Swtich

1

When using only one remote to control more than one camera, this switch will assign a unique ID to each camera

8. VISCA IN Port

For hard wired remote control from a 3rd party PC, joystick, etc...

VISCA OUT Port/RS485
 Used for daisy chaining multiple cameras for RS-232 RS-485 control

10. **DC IN 12V Socket**Only use the Power Adapter

supplied with this camera

# Specifications Camera & Lens

Odiliera & Lelis	
Video CMOS Sensor	1/2.8" CMOS 2.0 Mega Pixel
Frame Rate	30fps 1920 x 1080p, 30fps 1280 x 720p
Lens Zoom	20X Optical Zoom, 12X Digital Zoom f=4.7-90mm
Field of View	5° (tele) to 58° (wide)
Min Lux	0.5 Lux
White Balance	Auto/Manual/Outdoor/Indoor/One Push/ATW

# What's in the Box

What o in the Box
20X Zoom USB 3.0 Camera
12V/2.0A DC Power Adapter
Installation Bracket & Screws
USB 3.0 Data Cable (3m), Serial Control Cable, RS-232C to RS-485 Cable
IR Remote Control
User Manual (Also Downloadable Online)

Rev. 1.3 9/15

Pan/Tilt Movement		
Pan Movement	0-355°	
Tilt Rotation	Up: 90°, Down: 45°	
Presets	64 Presets, 4 Patrol lines	


Rear Board Connectors		
Video Interface	USB 3.0	
Control Signal Interface	Mini DIN-8 (VISCA IN, VISCA OUT/RS485)	
Control Signal Config.	DIP-Switch Pin 7/TTL Signal	
Baud Rate	9600 bps	
Power Supply Interface	DC 12V 2A	

Electrical Index		
Power Supply Adapter	12V DC 2A	
Input Voltage	12V DC (10.5-14V DC)	
Input Power	24W (Max)	
Working Enviornment	Indoor	
Quality Management System		

,	
Material	Aluminum, Plastic
Dimensions	5.68"W x 5.63"H x 5.88"D (7" H w/ Tilt up)
(W x H x D) mm	145mm x 143mm x 150mm (178mm H w/ Tilt up
Camera Weight	2.52 lbs (1.14 kg)
Box Dimensions	13.25"x9.25"x9.5" (337mm x 235mm x 242mm)
Boxed Weight	5.8 lbs (2.63 kg)
Operating Temperature	e 32°F to + 113°F (0°C to 45°C)
Color	Silver Gray

Certified ISO9001: 2008

# Remote Contol



#### 1. Reset

Restarts the camera and restores it to Factory Default settings. (Note: Will delete all memory)

**Physical** 

# 2. Camera Selection

Select Camera ID: 1, 2 or 3

# 3. Preset Positions

1-9: Preset Positions Set: Setting Preset Position Clear: Clear Preset Position Call: Call Preset Position Note: If you want to set (or call) the first preset position to 1, you should press number key "1", then press "Set" (or "Call") to set (call) the position

#### 4. Fast Zoom in/out Control Zone

- +: Zoom in quickly
- -: Zoom out quickly

## 5. Pan/Tilt Controller

- Move Down
- Move Left
- Move Right
- Auto Pan

## 6. Additional Function Zone

Freeze: Image Freeze BL: Back-light Compensation WB: White Balance AE: Auto Exposure D Zoom: Digital Zoom

# 7. Power Supply Switch

Switch for turning camera on (i.e. Stand-By mode vs. Working mode)

#### 8. OSD Menu Zone

Dome OSD: Enter Pan Tilt Zoom OSD menu Lens OSD: Enter lens OSD menu

### 9. Slow Zoom In/Out Zone

- +: Zoom in slowly
- -: Zoom out slowly

#### 10. Focus Control Zone

Auto: Turn on auto focus Manual: Turn on manual focus Far: Set focus at farther distance Near: Set focus at nearer distance

#### 11. Pan/Tilt Function Zone

L-Limit: Set left boundary limit scanning position Scan: Enable Boundary Scanning (Auto Panning) R-Limit: Set right boundary limit scanning position Home: Go to camera's Home position Tour: Enable automatic patrol tour of presets Rev: Enable image flip for ceiling mounting

> Still have questions? Give us a call.



152 Robbins Road